



Hook & Loop Placement

Cut 2 Each: PUL lining
Cotton exterior

1/4" seam allowance

Other required notions:
4.25" of 1" wide hook & loop tape
12" of double fold bias tape
(not extra wide!)

Directions

1. Using pattern piece, cut out 2 each of PUL liner fabric and quilting cotton exterior fabric.
2. Cut both hook and loop 1" tape to 4.25" in length. Then cut both hook and loop strips in half lengthwise to yield a .5" X 4.25" length of each. (Use the other set for a second bag.)
3. Using placement mark as a guide, sew hook tape to one plastic side of PUL liner, and loop tape to the other.
4. Leaving long straight edge open, sew liner pieces right side together.
5. Leaving long straight edge open, sew exterior pieces right side together.
6. Turn exterior right side out, pressing if necessary. Set liner inside exterior, aligning seam allowances. Use paper clips to hold the lining and exterior in position instead of pins.
7. Bind raw edges of bag with double fold bias tape, opening it up and turning under the binding's raw edge first 30° one way and 30° the other to entirely eliminate raw edges from showing.
8. Do another!